


- Wear appropriate personal protective equipment. Lab coats must be buttoned and back-closing laboratory gowns tied, if utilized, for greater protection. Gloves should be pulled over the wrists of lab coats, not worn inside the sleeve.
- Manipulation of materials inside the cabinet should be delayed for 1 minute after placing hands/arms inside the cabinet to allow the air to stabilize and to “air sweep” arms.
- Do not rest arms on front grille (unless the BSC is specifically equipped with features that permit this action) because doing so allows room air to flow directly into the work area rather than being drawn through the front grille. Instead, work with both arms raised slightly.
- Do not block the front grille with papers or other materials.
- Perform all operations on the work surface and at least 4 inches from the front grille.
- Allow cabinet blowers to operate for at least 3 to 5 minutes before beginning work to allow the BSC to “purge” particulates.
- If necessary, use plastic-backed absorbent toweling on the work surface (but not on the front grille) to aid in cleanup and spill containment.
- Make sure that active work flows from the clean to contaminated area across the work surface.
-



side of the BSC; upright pipette collection containers should not be used in the BSC and/or placed on the floor outside the BSC. (Instead, horizontal discard trays containing an appropriate chemical disinfectant should be used).

- Use the aseptic techniques below to reduce splatter and aerosol generation:
  - Opened bottles or tubes should not be held in a vertical position.
  - Hold the lid above open sterile surfaces to minimize direct impact of downward air.
  - Open flames should not be used because they create turbulence that disrupts the pattern of air supplied to the work surface.
  - If absolutely necessary to do so, touch plate microburners that provide a flame on demand or electric furnaces are available and should be placed in the back third of the BSC. All flames must be turned off before disinfectants are used.
- Aspirator bottles or suction flasks should be connected to an overflow collection plastic flask containing an appropriate disinfectant, and to an in-line HEPA filter and located in the back corner of the BSC.
- If spilled liquid enters through the front or rear grilles, close the drain valves and pour decontaminating solution into the drain pans. Use the appropriate decontamination solution and

**This is one in a series of informational fact sheets highlighting OSHA programs, policies or standards. It does not impose any new compliance requirements. For a comprehensive list of compliance requirements of OSHA standards or regulations, refer to Title 29 of the Code of Federal Regulations. This information will be made available to sensory-impaired individuals upon request. The voice phone is (202) 693-1999; the teletypewriter (TTY) number is (877) 889-5627.**